

Use the following steps to install the FrameLink Express software supplied on a CD. Note that 'click' refers to the left mouse button.

1. If a version of FrameLink Express was previously installed on this machine, then you must first remove it:

## To remove the application files:

- 1.1 Click on "Start".
- 1.2 Click on "Settings".
- 1.3 Click on "Control Panel".
- 1.4 Double click on "Add or Remove Programs".
- 1.5 Click on "FrameLink Express".
- 1.6 Click on "*Remove*".
- 1.7 If the 'FrameLink Express InstallShield Wizard' pops-up then do the following, otherwise go to step 1.8: Click on "*Remove*".
  - Click on "Remo Click "Next".
  - Click "Yes".
  - Click "Finish".
- 1.8 Click on "Yes".
- 1.9 Click on "Close".
- 2. After having removed a previous version or if a version of FrameLink Express was NOT previously installed on this machine then:

## The first step is to install the application files:

- 2.1 Insert the FrameLink Express CD into the appropriate drive; the setup.exe file will run automatically. Note: If it does not start automatically, click on "*Start*", "*Run*", enter or browse to "(*CD drive*): *setup.exe*" and click "*OK*".
- 2.2 Wait for the "FrameLink Express InstallShield Wizard" screen to appear.
- 2.3 Follow the on-screen instructions.
- 2.4 For Windows XP 32 bit and Windows XP 64 bit, click "*Continue Anyway*" to continue.



2.5 For Windows Vista 32 bit and Windows Vista 64 bit, select "*Always trust* software from Imperx, Inc." and click on "Install" button, when the following message appears:





2.6 When the following message appears, choose if you would like to register online by clicking on "*Register now*" or "*Skip*".

MDEDY	Installation Complete
tling Edge Imaging Solutions*	Setup was completed successfully.
Installation complete	
Please take a few mom	ents to register your product on our website
We strongly suggest th software/firmware bec	iat you do this so that we can notify you when new omes available
Register now on Im	perx website

- 2.7 Click "Finish". This completes the software installation
- 2.8 Reboot your computer.

## The next step is to install the driver files:

- 2.9 Insert the FrameLink Express card into the computer.
- 2.10 For Windows XP 32 bit and for Windows XP 64 bit: Wait for the system to prompt you with a "Found New Hardware Wizard" dialog box. Proceed to Step 2.11.
  For Windows Vista:

The driver will automatically be installed. Proceed to step 2.15.

2.11 Under certain conditions, the following message may appear:



If this message appears, click "No, not this time", then click "Next".

2.12 When the following message appears, select "*Install the software automatically (Recommended)*", then click "*Next*".

Found New Hardware Wizard	
	This wizard helps you install software for: FrameLink Express Capture Card If your hardware came with an installation CD or floppy disk, insert it now.
	What do you want the wizard to do? Install the software automatically (Recommended)
	C Install from a list or specific location (Advanced) Click Next to continue.
	< Back Next > Cancel

2.13 The following message will appear:

Hardwa	re Installation
1	The software you are installing for this hardware: FrameLink Express Capture Card has not passed Windows Logo testing to verify its compatibility with this version of Windows. (Tell me why this testing is important) Continuing your installation of this software may impair or destabilize the correct operation of your system either immediately or in the future. Microsoft strongly recommends that you stop this installation now and contact the hardware vendor for software that has passed Windows Logo testing.
	Continue Anyway STOP Installation

- 2.14 Click "*Continue Anyway*" to continue.
- 2.15 When "Click finish to close the wizard" appears, click on "Finish".
- 2.16 This completes the driver installation.

For additional information and the latest updates and downloads, please visit our website at <a href="http://www.imperx.com">www.imperx.com</a>